

מוט טלסקופי המאפשר לחיצה על מתג חשמל ופתיחת דלתות

הוראות שימוש:

ניתן לענוד על הצוואר ולהשתמש לפי הצורך.

1. יש להימנע מפתיחת המוט הטלסקופי בקרבת ילדים אחרים על מנת למנוע פגיעה בהם.
2. יש לקפל את המוט חזרה למצבו הקצר בתום השימוש
3. יש להימנע משימוש במוט באם נפגם

השימוש במוצר באחריותו הבלעדית של המשתמש/ההורה/המטפל

قضيب تلسكوبي يتيح الإمكانيّة للضغط على مفتاح الكهرباء وفتح الأبواب

تعليمات الاستخدام:

يمكن ارتداء هذا الجهاز حول الرقبة واستخدامه حسب الحاجة.

1. يجب تجنب فتح العصا التلسكوبي بالقرب من الأطفال الآخرين لتجنب إصابتهم.
2. قم بطي العصا للخلف إلى وضعه الأقصر بعد الاستخدام
3. تجنب استخدام العصا في حالة تلفه

استخدام المنتج هو مسؤولية المستخدم / الوالد / مقدم الرعاية وحده

Telescopic stick that can flip a light switch and open doors

Can-be worn around the neck and use as needed.

1. Do not open the telescopic rod around other children to prevent injury.
2. The rod should be folded back to its short position after use
3. Avoid using the rod and if damaged

The use of the product is under the sole responsibility of the user / caregiver / parent